


Initial Standard Value Determination: Instrument Specific: Pocket Colorimeters

1. On an instrument that has been calibrated with a laboratory control standard, perform steps 1 to 4 of the Instructions for Quality Control Use.
2. Place the **blank** in the instrument with the alignment mark facing the user. Record the instrument reading. The reading should be within the tolerance limits of the value specified on the Certificate of Analysis.
3. Record the actual value obtained on the Record of Performance Verification and on the standard in the area provided.



4. Repeat steps 2 and 3 above for all standards

CAUTION • Use standards only with Hach Company instruments. Store standards in set box at room temperature in an upright position

AR506A 27080-89A

Bar Code

Lot A1234

Exp. May-08

